



*Water*  
*in*  
*Shenandoah County*



Shenandoah 2000 Galleries  
PO BOX 651, Bayside VA 22810  
540-856-8497

Cover Photograph by Shenandoah 2000 Galleries

**A Primer**  
**2007-2008**  
*Shenandoah County Water Resources*  
*Advisory Committee*

# **WATER IN SHENANDOAH COUNTY**

## **A PRIMER**

### **INTRODUCTION**

This document was prepared by the Shenandoah County Water Resources Advisory Committee for the use of the elected and appointed officials of the county and the incorporated towns as well as all citizens of the county who wish to learn more about this most vital of natural resources — our water. The information contained herein was compiled from a number of sources including: The Report of the Shenandoah County Commission on the Future, the United States Geological Survey (USGS), the Environmental Protection Agency (EPA), Virginia Department of Environmental Quality (DEQ), Virginia Department of Conservation and Recreation (DCR), Virginia Department of Health, Virginia Water Resources Research Center at Virginia Tech, and the Northern Shenandoah Valley Regional Commission.

### **GROUND WATER (GW)**

1. This should perhaps more aptly be called “underground water” because that is where it is located.
2. Eighty percent of the residents of Shenandoah County

(and of Virginia) rely on GW for their water supply.

3. Groundwater is a finite resource. Worldwide, for every 3 gallons of GW that is taken only 2 gallons replenishes it. The long term implications of this phenomenon are awesome. There is no reason to think that the Shenandoah Valley is exempt from the consequences of this.

4. By law (Clean Water Act and Safe Drinking Water Act), Virginia is committed to protecting all state waters, including GW. Keys to ensuring quality of GW are educating citizens about the importance of GW protection and prevention of GW contamination.

5. Leading uses of GW in Virginia :

• Rural use (livestock & domestic)	39%
• Public supply (water utilities)	30%
• Industrial	29%
• Irrigation	2%
• Thermoelectric	1%

6. The water table is the upper boundary of the zone in the ground where all pores of the underlying material are filled with water. Water in this zone is called GW. At the water table the hydraulic pressure is equal to atmospheric pressure. Below the water table, hydraulic pressure increases with increasing depth.

7. Both the quality and quantity of GW can be affected by the condition of the layer of earth and rock above the water table in a recharge area [example: overuse of fertilizer, poorly maintained septic systems]

8. Water bearing formations in the ground are commonly referred to as aquifers.

9. Granite, slate, and limestone are solid rock masses typical of the Shenandoah Valley. GW forms in pores, cracks, fissures, and solution channels (unique to limestone due to dissolving action.) Once solution channels have become developed they function more as pipes than sponges. The size, number, and extent of solution channel interconnections vary among deposits and from region to region. Some channels are so well connected that they resemble streams. The capacity of an aquifer to store and transmit water is governed by the size of cracks and solution channels and the number of their interconnections.

10. The orientation of cracks and fissures in nonporous rocks, e.g., limestone, can cause complex GW flow patterns that are quite different from surface flow patterns. That becomes important in locating septic systems relative to wells. The surface topography cannot be depended upon to accurately reflect the water table's topography. It requires more detailed study to ensure the septic system is truly built "downstream."

11. The length of time water remains underground varies greatly. Some remains underground for only days or weeks. Other water may remain as long as 10,000 years.

12. Most of the recharge of GW aquifers occurs during the winter. More precipitation falls between April and September than between October and March, but because of longer days and higher temperatures and the growth of vegetation during the summer months almost all of the rainfall is consumed through evaporation, evapotranspiration (through vegetation) and surface runoff. After mid-May the GW levels typically begin to decline and continue to do so throughout the growing

season. Thus it is vital to GW recharge that adequate rainfall and snow occur during the winter months when evaporation and evapotranspiration are not a factor.

## KARST

1. Landforms that are produced primarily by the dissolution of rocks, mainly limestone and dolomite (carbonates) are known as karst. In Shenandoah County much of the valley between the North Fork and the hills to the west is made of this karst landform. Karst characteristics include:

- numerous sinkholes
- an underground drainage network that consists of solution openings that range from enlarged cracks in the rocks to caves and large caverns.
- highly disrupted surface drainage systems which relate directly to the unique character of the underground drainage system

2. Ground water recharge is very efficient in karst terrain. Precipitation readily infiltrates through the rock openings in the land surface (but this enhances the potential for contamination).

3. Springs may be a combination of slow-moving water draining from pores in the bedrock and rapidly moving storm-derived water. The slow moving water reflects the chemistry of the aquifer materials; the rapidly moving water the chemical characteristics of precipitation and surface runoff.

4. Water movement in karst is especially unpredictable. In some cases true underground streams with high rates

of flow equivalent to rates of flow in surface streams are found. It is not unusual for medium-sized streams to disappear into rock openings and reappear at the surface elsewhere. This is called "ground water under the influence of surface water."

5. Seeps and springs are characteristic features. Large springs (having large GW recharge areas) often are the source of small to medium-sized streams and tributaries.

6. Because of the complex patterns of surface water and GW flow in karst terrain, the drainage divides of each do not coincide.

7. Portions of the Shenandoah Valley with karst consistently form the most productive aquifers in Virginia's consolidated rock formations. Ridges and upland areas, however are often underlain by sandstone and shale which yield only enough water for rural and domestic supplies.

8. Rapid movement of GW in karst areas makes the pollution potential high. Contamination can spread over wide areas. Aquifers are often recharged directly by streams crossing fault zones. Wells in the fault zones generally have the greatest yields (and greatest potential for pollution).

9. As more scientific evidence becomes available about karst it is becoming increasingly apparent that its unpredictable GW supply and movement and its high potential for contamination call for a high level of awareness and diligence on the part of those who inhabit karst terrain (which is most of us who live in Shenandoah County).

## **SURFACE WATER (SW)**

1. SW is found primarily in streams and rivers but is also in lakes, ponds, and reservoirs. Surface runoff is the prime source of water for these rivers and streams and impoundments, but GW is also an important contributor through the numerous springs in the county and through subsurface connections between GW and stream channels.

2. About 72% of annual precipitation returns to the atmosphere through evaporation from the surface or vegetation; the remaining 28% is divided about evenly between running off the land directly to become stream-flow or infiltrating the soil to become GW.

3. The stream system in the county is part of the Shenandoah River Watershed which in turn flows into the Potomac River and ultimately the Chesapeake Bay and Atlantic Ocean. Eventually all surface water in the county flows into the North Fork, which averages 380 MGD (million gallons per day) although readings as low as 22 MGD and as high as 39,000 MGD have been recorded. The North Fork is supplied by some 10 major streams, including Mill Creek, Smith Creek, Holmans Creek, Stony Creek, Cedar Creek, and Tom's Brook.

4. The Virginia Department of Environmental Quality (DEQ) evaluates the surface water quality in Virginia as to its suitability for fishing and swimming. In its most recent report DEQ listed segments of the North Fork, Holmans Creek, Smith Creek, Mill Creek and Toms Brook as "impaired waters," meaning that they exceed the state's standards in one or more of the following types of pollution: fecal coliform bacteria, excessive nutrients (nitrogen and/or phosphorous), PCBs, or impaired aquatic

organisms living on the stream bottom. For each of these streams the state will establish a Total Maximum Daily Load (TMDL) allowable of the offending pollutants, and DEQ has the responsibility to follow through to see that each stream's TMDL is achieved by the year 2010.

5. The towns of Woodstock and Strasburg draw their drinking water supplies from the North Fork and process it through treatment plants before providing it to the public. Drinking water for the towns of New Market, Mt. Jackson, Edinburg, the Stony Creek and Toms Brook/Maurertown Sanitary Districts and all other public water systems (defined as serving 25 or more people) comes from wells, i.e., GW sources.

6. The North Fork and some of its tributaries are also the source of water for numerous farms (irrigation) and industries along their courses. They also receive discharges from permitted wastewater treatment plants and impoundment lagoons.

7. Surface water streams are also used for recreation, scenic appeal, and aquatic habitats for fish and wildlife. They are an important economic resource for the county.

8. The Northern Shenandoah Valley Regional Commission recently sponsored a three-year Minimum Instream Flow (MIF) study for the North Fork. It was completed in 2003. The study defined the minimum flow requirements of the river to support the expected functions such as water supply for the towns, recreation, and aquatic habitats. The MIF will provide a basis for reconciling conflicts between in-stream and off-stream uses of water in the North Fork watershed, particularly during periods of drought.

9. Surface water has its own vulnerabilities to contamination (ref. para. 4 above), primarily from runoff from the landmass containing excess amounts of nitrogen and phosphorus from fertilizers; chemicals from excessive use of pesticides; nitrates, bacteria and viruses from failing septic systems; and nitrogen and phosphorus from improper management of animal wastes. Runoff containing the pollutants described above can come from either agricultural or urban/suburban sources and needs to be managed by landowners responsible for applying fertilizers and chemicals on their property.

### **INTERACTION OF GW AND SW**

Underground aquifers do not act solely as water receivers. They are not "dead ends" in the hydrologic cycle. Approximately 30% of the flow of surface streams is from GW sources. During periods of heavy rainfall or rapid snowmelt, surface runoff is the primary contributor to stream flow. When no surface runoff is occurring, GW in the form of springs is the only contributor to a stream's flow.

### **NUTRIENT MANAGEMENT**

1. The quality of water for human consumption and for aquatic habitat can be seriously affected by high levels of nutrients (nitrogen and phosphorus). Excess nutrients coming from sources in the Shenandoah River basin have an impact on local water quality as well as on the living resources of the Potomac River and the Chesapeake Bay. Excessive nitrate in drinking water can cause human health impacts. High levels of nutrients also lead to increased algae which can cause taste and odor problems

in drinking water. As algae increases it blocks light from reaching underwater grasses. As algae die and sink to the bottom their decay robs the water of dissolved oxygen which is essential for fish, shellfish and other aquatic animals to survive.

2. Virginia is a signatory to the Chesapeake Bay Agreement which calls for major reductions in nutrients (nitrates and phosphorus) and sedimentation throughout the Potomac and Shenandoah River basins before the year 2010. Achieving the nutrient reduction goals and then capping them at those levels poses a significant challenge to all jurisdictions that reside within the Chesapeake Bay watershed.

3. Agricultural best management practices (BMPs) have been found to be the most cost effective methods for reducing non-point source nutrient loads. Farmers are assisted in this regard by the Lord Fairfax Soil and Water Conservation District, the Natural Resources Conservation Service, Virginia's Department of Conservation and Recreation, the Cooperative Extension Service, and others. Other measures include implementation of erosion and sediment control plans, education programs for homeowners to reduce over-use of fertilizers and promote home conservation techniques, adoption of stream buffers for new development, and pump-out of septic tanks at regular intervals.

### **WELLS**

1. A well yield of at least 6 gallons per minute is needed for home use, although 10 is more desirable. Low yield wells (4 gallons or less) should have a storage tank four or five times larger than daily consumption (75 gals per

person on average).

2. Grout to a depth of 20 feet or more is used to seal the space between the well casing and the bore hole. This is to prevent well contamination from surface sources around the wellhead. Also a tightly fitting cap should be installed to keep out dirt, rodents, and other foreign material. It is especially important that abandoned wells be capped inasmuch as the aquifer for each well is connected with other wells in the vicinity. Virginia's Private Wells Regulation, VR 355-34-100, Section 3.11 sets procedures for permanently abandoning a well. Check with the county health department for details.

3. To prevent contaminated runoff water or other materials from entering a well, it should be located on the highest suitable ground and far from potential pollution sources. Virginia state regulations (VR 355-34-100) govern minimum distances between a well and structure or topographic feature. Some examples for private wells:

Building foundation	10'
Building foundation (termite treated)	50'
House sewer line	50'
Septic tank	50'
Drainfield	100'
Underground storage tank	100'
Barnyard, hog lot, etc.	100'

4. Well water for drinking purposes should be tested for bacteria once per year and for harmful chemicals every three years. Testing should be done immediately if an unexplained gastrointestinal illness occurs or if water taste or color changes suddenly. There are over 100 public and private laboratories certified to test drinking water quality in Virginia. Check with the county health

department for list of labs and the procedures involved in testing. Alternatively, consult the Yellow pages under "Water Analysis" if you wish to have your water tested professionally.

5. If your well test reveals the presence of harmful bacteria (fecal coliform or E-coli) you will need to take positive action. Continuing to drink the water from the well should not be an option. Consult your Yellow pages under "Water Treatment" for companies that deal with this problem. A relatively simple "shocking" of the well with a chlorine solution may solve the problem if the contamination is confined to the piping or if the well is only temporarily contaminated. Follow the instructions of the water treatment company. If, on the other hand, the aquifer that feeds the well is contaminated, locating the source or sources may be difficult if not impossible. In this case, you will need to install a permanent disinfection system in your household water system. Again consult a water treatment company for assistance.

6. Conditioning, as distinguished from disinfecting, of the home water supply makes the water more pleasing to the senses, that is, makes it feel softer, taste and smell better, etc. Water softening and filtering are the most common methods of conditioning well water.

## **WASTEWATER TREATMENT**

1. Municipal wastewater treatment plants process sewage waste from the towns and sanitary districts they serve. Through a process of chemical treatment, filtering, and aeration the effluent is decomposed and cleansed of bacteria, viruses, and other harmful ingredients before being discharged into the North Fork or Stony Creek.

The ensuing discharge water must meet standards set by the state.

2. The liquid wastes produced by processing and rendering plants, fertilizer production operations, and a wide variety of other commercial activities are often disposed of in surface impoundments where they are treated by aeration. Impoundments are permitted by the state through the Virginia Pollutant Discharge Elimination System (VPDES). The permit system allows for subsequent discharge into surface waters provided that standards on the quality of the discharge water are met.

### **CONTAMINANTS**

1. Treating contaminated GW is difficult and expensive. The natural degradation of pollutants in GW occurs very slowly. Contamination may go undetected for years and is almost always discovered by accident or after people become ill. Preventing contaminants from reaching GW is a better approach.

2. *Point Source (PS)* pollution originates from definable points such as industrial and municipal discharges. Point source pollution can be managed by treatment and monitoring at the specific discharge points through the state-run permit process. *Nonpoint Source (NPS)* pollution on the other hand presents a more difficult problem. NPS pollution comes from many different sources (agricultural runoff, road construction, residential development, storm sewers, and septic tanks, to name a few). NPS pollution comprising so many potential impacts and originating from so many potential sources presents a difficult management challenge.

3. Major sources of contamination:

- **Leaks and spills of petroleum products**

- Oil and gasoline contain hydrocarbons that are soluble in water. Small concentrations (less than .005 mg/L) can be detected by taste or smell and make water unfit for human consumption.

- Underground storage tanks (USTs), many buried since WWII. DEQ initiated a program in 1989 to register and regulate them. Funds are available to finance cleanup of leaking USTs.

- Buried home furnace oil tanks. Generally thin-walled and easily corroded.

- Used motor oil. Over 4 million gallons are disposed of improperly in Virginia each year.

- **Landfills**

- The average household generates 4.5 pounds of trash per day.

- Federal and state regulations govern the design, construction, and operation of all landfills (government or private). They require special monitoring wells to check for GW contamination, bi-annual analysis of GW samples, and remediation of GW contaminated by leachate liquids. All new sanitary landfills must have special clay and plastic liners.

- Leaching is the main problem in sanitary landfills.

If leachate is not captured and treated it can contaminate GW. EPA estimates that 25% of the worst toxic waste sites in the U.S. are former landfills.

- **Hazardous Waste**

- Superfund Sites administered by EPA and DEQ. Currently there are 18 private and 7 federal facilities in Virginia. None are in Shenandoah County.

- **Septic Systems**

- Are the most frequently reported sources of GW contamination in the U.S.

- The design life of septic systems averages 15 years. Older systems, though still in use, have exceeded their design life and may no longer be functioning properly.

- In addition, improperly sited septic systems may allow drainfield effluent to move too rapidly for adequate treatment by the soil. In karst, where GW flow rates can be high, bacteria and viruses may be transported several miles and live below the water table for many days or even months.

- Even properly functioning septic systems should be periodically inspected and maintained.

- When many septic systems are concentrated in a small area, their combined wastewater flow may exceed the soil's treatment capacity. This can be a problem for densely spaced residential developments.

- In soil conditions unsuitable for conventional septic systems so-called "alternative systems" may be approved. Such systems are more expensive and complex than conventional systems and require regular professional maintenance and inspections. The county health department can provide details on alternative systems and requirements.

- Homeowners should not dispose of insecticides, herbicides or other chemicals in toilets and sinks. Septic systems are not designed to treat these materials. They can contaminate nearby GW and destroy beneficial microorganisms in the septic tank and soil.

- In areas with inadequate soil or dense development, septic systems can cause noticeable increases of nitrate in GW. EPA standard is 10 parts per million (ppm) for drinking water. At this level water should not be consumed by infants or pregnant women. If nitrate-laden GW reaches surface water it can cause algae blooms.

- **Agricultural Activities**

- Use of fertilizers and pesticides and storage or disposal of animal wastes all can cause degradation of GW quality. It depends on the rate of application, decomposition rates, level of water solubility, soil properties, and depth to GW.

- Nitrogen in the form of nitrate is the fertilizer nutrient that most commonly contaminates GW beneath agricultural lands. Other sources of nitrate: human and animal wastes, atmospheric deposi-

and spectators away from a septic tank when it is being cleaned or repaired.

- Keep vehicles and heavy equipment off septic systems, including tanks, drainfields, and other components.

- Do not pour or flush toxic substances such as paints, varnishes, photographic solutions, paint thinners, waste oils, pesticides, antifreeze and household cleaners that contain lye or petroleum distillates into the household plumbing system. These materials pass through the septic system without being treated and contaminate ground water. Moreover, they can destroy the beneficial bacterial action in the septic tank. Take these materials to the landfill reception point.

- Purchase biodegradable household products that are eventually destined for the septic tank, such as laundry detergents, cleaning products, and even toilet paper. READ THE LABELS.

- If the kitchen has a garbage disposal use it sparingly. Kitchen wastes decompose slowly in the septic tank environment and can unnecessarily increase the buildup of sludge in the tank. A good rule of thumb: don't put anything into the septic system that could otherwise be put in the family garbage container.

- **THE BOTTOM LINE ON SEPTIC SYSTEMS: THEY ARE DEFINITELY NOT THE SAME AS BEING ON A SEWER SYSTEM. TO AVOID TROUBLE THEY NEED TO BE MANAGED CAREFULLY.**

- **Land use:**

- Clean out sinkholes and fence them. Sinkholes provide a direct source of contamination to ground water.

- Locate livestock pens and barns as far downhill from the well as possible.

- Utilize sound agricultural practices to reduce soil erosion and prevent surface runoff. Riparian landowners should maintain streambank vegetation, fence cattle out of the stream, and minimize disturbances in riparian areas. Landowners can apply to the USDA's Natural Resources Conservation Service to have riparian land placed in the Conservation Reserve Program (CRP).

- To reduce the levels of unused nitrates, use slow-release fertilizers, apply nitrogen fertilizer in small amounts during the growing season as needed, and rotate crops with legumes. Using soil tests to determine the need for fertilizers in different soil types can save farmers and homeowners money as well as reduce the risk of GW and SW contamination.

- **Household Habits**

- Routinely check for leaks in underground storage tanks used to store home heating oil or gasoline. Any smell or taste in drinking water, unexplained loss of fuel in tank, or oil slick should be investigated immediately.

- Clean up any open dumps where household trash, construction materials, automobile tires and batteries, old appliances, and other waste items are discarded. Such open dumps endanger GW, particularly in karst terrain as found in Shenandoah County, and are illegal in the state of Virginia.

- Collect used motor oil for recycling at oil collection centers or the county landfill (check local service stations for one that accepts used motor oil for recycling). A single quart of oil on the ground can contaminate 2 million gallons of drinking water!

- Recycle. Anywhere from 30 to 75 percent of the materials found in an authorized landfill could have been recycled for use in industry or agriculture. Recycling the maximum amount of waste possible helps to solve the waste disposal problem, offers an alternative to the use of new resources, and conserves energy.

- **Water conservation**

- With the periodic droughts that occur in the Shenandoah Valley it is a waste of water and time to try to keep lawns green. Let them go and they will recover when natural rainfall resumes.

- Use soaker hoses, the drip method, or hand-held hoses to water exterior flowers, shrubs, and trees.

- Select more drought-tolerant vegetation and plant species for landscaping and use mulches to retain moisture.

- Limit vehicle-washing activities. If you are washing, use a bucket, not a hose. Use commercial car washes that reuse their water.

- Sweep sidewalks and driveways — don't hose them down.

- Cover pools and spas when they are unoccupied to reduce evaporation.

- Inspect and repair all leaking faucets, pipes, hoses, and toilets.

- Take short showers instead of baths. Consider bathing young children together.

- Don't run water while shaving, brushing teeth, or washing dishes by hand.

- Retrofit existing showers and faucets with inexpensive flow restrictors.

- Install conservation equipment, such as a brick or a water-filled bottle in the toilet tank to reduce water used per flush. Half of all household water usage is in toilet flushes. Newer low water consumption toilets are on the market and are required in new homes.

- Run dishwasher and washing machine only when filled to capacity. Use economy settings.

- When agricultural spray irrigation is practiced it should be limited to low evaporation periods. Evaporation rates are highest when the sun is out and the temperature is high.

- **Well Management**

- If the yield rate (in gallons per minute) is not known, the county health department or the well driller should be able to furnish it. This rate should be thought of as the absolute maximum, not the sustained rate. It is better to pump water at a sustained low rate than to pump the same volume of water at or near the rated yield.

- If the water pressure drops or the water becomes cloudy, let the well rest overnight. This is a wake-up call that the well is being overtaxed. A cutback in daily water usage is highly advisable.

- Test the well water for bacteria and harmful chemicals at periodic intervals (see earlier section on **Wells**).

- Regularly inspect the wellhead and the area around it for condition of the cap, presence of pooled water around the casing, contaminants in the vicinity, etc.

- **Precaution for Home Buyers**

- Have present owner provide written information about the well — location, age, depth, rated yield, depth of case grouting, age of pump and piping if more recent than the age of the well. If there is a septic system, obtain its location, age, and maintenance records.

- Have the water tested by a laboratory and the

household plumbing and the wellhead checked by a plumber.

- Have septic system pumped and condition checked by a certified inspector.

- Before buying undeveloped property, check with the county health department about perk tests and septic system construction regulations. If a well needs to be drilled, check with neighboring land owners, well drillers, the health department, and the county extension agent about well depths, well yields, and groundwater quality in the area. Keep in mind that local variations are such that water may not be found at the same depth and quantity as one's neighbor.

**EVERY CITIZEN HAS A SIGNIFICANT  
DEGREE OF CONTROL OVER THE  
QUALITY AND QUANTITY OF THE  
WATER SUPPLY**